

WARNING



ONLY USE THE ELLIPTICAL WHILE SITTING!!!



DO NOT STAND ON THE ELLIPTICAL MACHINE!!!



WHEN POWER IS OFF OR NOT PLUGGED IN

You can pedal **forward** or **backward** of the elliptical machine when it is not plugged in or power off.



MOVING THE PRODUCT

Always use the **built-in handle** to carry or move the elliptical machine.



PRODUCT CARE



STORAGE

- When not in use, place the machine into a box and place in a dry, ventilated, cool area.
- Do not twist the power cord.
- Do not place the machine in direct sunlight or heat.
- Do not store where there is high humidity, such as the bathrooms.



CLEANING

- Before cleaning, make sure to unplug the power cord.
- Use a dry cloth to clean the surface of the machine.
- Do not use corrosive cleaning agents to clean the machine.



TROUBLESHOOTING

If you have problems when using this product, refer to the following tips and possible solutions.

Status	Possible Cause	Solution
Product doesn't turn on	Not powered	Make sure power cord is plugged in.
Product suddenly stops operating	1. Power failure. 2. Timer exceeded 30 minutes. 3. Continuous use time is too long, overheat protection. 4. Beyond Max User Weight stand on the pedal.	1. Check whether the plugs on both sides of the power cord are connected. 2. Press the Power button to turn the machine on. 3. Let the product cool down, then turn power on again. 4. Don't stand on or use it beyond max user weight.



IMPORTANT: Read all instructions carefully before using this product. Retain this manual for future reference.



www.pinners.es



customerservice@pinners.es

04



5. EC DECLARATION OF CONFORMITY

Pinretail SL, located at Ronda Sant Ramon 132, 08830 Barcelona, hereby declares under our sole responsibility that the following product:

- Product Name:** Electric Elliptical Machine
- Model/Reference:** FBA2407

Is in conformity with the relevant European Union harmonization legislation:



- 1. Low Voltage Directive (LVD) 2014/35/EU**, ensuring the electrical safety of the device (Rated voltage: 110V-220V, Rated power: 50W).



- 2. Electromagnetic Compatibility (EMC) Directive 2014/30/EU**, ensuring the equipment does not cause or suffer from electromagnetic interference.



- 3. RoHS Directive 2011/65/EU**, on the restriction of hazardous substances.



- 4. WEEE Directive 2012/19/EU**, regarding the disposal of electrical waste.

ELECTRIC ELLIPTICAL MACHINE

USER MANUAL / INSTRUCTION MANUAL



WARNING

**ONLY USE THE ELLIPTICAL WHILE SITTING!
DO NOT STAND ON THE ELLIPTICAL MACHINE!**



IMPORTANT

Read all instructions carefully before using this product. Retain this manual for future reference.

Thank you for purchasing the Electric Elliptical Machine. Please read the operating instructions **carefully** before use, especially the safety instructions.



CORRECT USE
Use only while sitting.



INCORRECT USE
Do not stand on the machine.

The Elliptical Machine can only be used by sitting!



MULTILINGUAL INSTRUCTIONS

Scan the QR code or visit our website to access this manual in other languages.



www.pinners.es



customerservice@pinners.es

SAFETY INSTRUCTIONS



Be sure to use this product in accordance with the operating instructions.



1. ELECTRICAL SAFETY

- 1 Turn off the power after each use. After using or before cleaning the machine, unplug the power supply from the outlet.
- 2 Do not operate the machine with wet hands.
- 3 Do not allow water and other liquids to touch control switch.
- 4 Do not place the power cord under the product or any heavy object.
- 5 Do not wind the power cord around the product. That could damage the power cord, cause electric shock or electrical fire.
- 6 If the power plug is loose, do not use the product.
- 7 Do not use the power cord to move the product.
- 8 The product's rated voltage fits 110V-220V, rated power is 50W.



2. SAFE USE

- 9 Do not cover while using, to avoid motor overheating and cause malfunction or damage.
- 10 Keep children away from the equipment. This machine is for adult use only.
- 11 If you feel uncomfortable or experience any adverse symptoms, stop the using the machine immediately.
- 12 Do not use the product if it is damaged or defective.
- 13 Do not insert or place any debris in the product.
- 14 Use the elliptical indoors on a level surface, and keep at least 3 feet off respace all around it.



3. MEDICAL / HEALTH

- 15 Do not use with other medical electronic equipment, such as pacemakers or EKG machines.
- 16 Consult your physician, especially if you have any medical conditions such as diabetes.



4. ENVIRONMENT

- 17 Do not use the product in wet or dusty environment. Do not use in humid environment, such as bathroom.
- 18 Do not store or use the product outdoors. Keep the product away from direct sunlight.
- 19 If there is a power surge during use, stop using the product. Sudden restoration of power could injury you.



IMPORTANT: Read all instructions carefully before using this product. Retain this manual for future reference.



www.pinnners.es



customerservice@pinnners.es

02



OPERATING INSTRUCTIONS

- 1 Insert the power cord into the elliptical machine and connect the power.
Four horizontal lines indicate that the machine is powered on.
- 2 Press the red "POWER" button to turn on the power.
Power Button: Control the electric elliptical machine start or stop.



The elliptical machine will automatically shut down after 30 minutes of use, and the elliptical machine will emit beep.



CONTROL PANEL DISPLAY

	SCAN	Press FUNCTION until the SCAN light comes on, and the screen will automatically display the reading of each function every 5 seconds
	TIME	Press FUNCTION until the TIME light is on, the actual training time will be displayed on the screen, and the maximum working time is 30 minutes
	DISTANCE	Press FUNCTION until the DISTANCE light is on, and the screen will display the walking distance (m)
	SPEED	Press FUNCTION until the SPEED light comes on, and the screen will display current speed
	COUNTERS	Press FUNCTION until the COUNTERS lamp lights up, and the screen will display the accumulated turns
	CALORIE	Press FUNCTION until the CALORIE light is on, and the screen will display the current calorie



MANUAL OPERATION

- 1 Press the red POWER button of panel, the HA is on but does not blink.
- 2 When the POWER button is pressed a second time, the HA flashes, start the slowest operation and the elliptical machine enters the manual mode. You can adjust the buttons on the panel as needed.



If you use the remote control, first press POWER, and then press START/STOP after HA appears. The HA flashes. After the machine starts to run, press MANUAL, and then press SPEED up and down to switch speed.

- D** **DIRECTION:** press this button to change the machine working direction.
- S** **SPEED:** 5 speed levels. Press this button to increase or decrease the speed, such as HA-1, 2, 3, 4, 5.
- F** **FUNCTION:** press this button to switch between time, distance, speed, counter and calories.



AUTOMATIC OPERATION

- 1 Press the red POWER button of panel, the HA is on but does not blink;
- 2 Press the MODE button once for P1, twice for P2, thrice for P3.
- 3 Select the mode you like, press the POWER button for the second time, the mode indicator will flash, and the elliptical machine will enter the automatic mode.



If you use the remote control, press POWER first, after HA appears, press P1, P2, P3 to select the mode. After completing the mode selection, the mode indicator will flash, the machine will start by itself without pressing other buttons.



The pedals will rotate at different speed or direction in different Auto Modes.
In Auto Mode, speed and direction cannot be adjusted.



NOTES:

The machine needs to be stopped when it is running:



- **Panel:** when the machine is running, press the POWER button to stop;
- **Remote:** when the machine is running, press the START/STOP button to stop.



The machine needs to be turned off when it is running:

- **Panel:** when the machine is running, press the POWER button to stop, wait for 1 minute, and the machine will return to the closed state of four horizontal lines;
- **Remote:** when the machine is running, press the POWER button, and the machine will return to the closed state of four horizontal lines.



The indicator lamp flashes and the machine is about to enter operation.



Use the remote control to directly switch between manual mode and automatic mode (P1, P2, P3).



IMPORTANT: Read all instructions carefully before using this product. Retain this manual for future reference.



www.pinnners.es



customerservice@pinnners.es

03